



.: www.totalrecallvr.com :.

Infinity ES^x Appliance

Quick Start Guide

February, 2024

Guide Issue 2.0

Total Recall VR Infinity Release 20.5.0

Copyright © 2024 [Prolancer Pty Ltd](#), Sydney, Australia.

Prolancer Pty Ltd licenses the text and illustrations in this document under a Creative Commons Attribution–Share Alike 3.0 Unported license ("CC-BY-SA"). An explanation of CC-BY-SA is available at <http://creativecommons.org/licenses/by-sa/3.0/>. By CC-BY-SA, if you distribute this document or an adaptation of it, you must provide the URL for the original version. Prolancer, as the licensor of this document, waives the right to enforce and agrees not to assert Section 4d of CC-BY-SA to the fullest extent permitted by applicable law.

Total Recall VRTM is a trade mark of Prolancer Pty Ltd. in Australia and other countries. All other trademarks are the property of their respective owners.

The information in this publication is subject to change without notice. Prolancer Pty Ltd assumes no responsibility for any errors that may appear in this publication.



Prolancer

Related Documents:

- [1] Prolancer Pty Ltd, Total Recall VR website. Available from:
<http://www.totalrecallvr.com/>.
- [2] Prolancer Pty Ltd, Prolancer website. Available from:
<http://www.prolancer.com.au/>.
- [3] Prolancer Pty Ltd, Total Recall VR Infinity Overview User Guide, 2.0, February 2024
- [4] Prolancer Pty Ltd, Total Recall VR Cockpit User Guide, 2.0, February 2024
- [5] Dell, Dell EMC PowerEdge R450 Technical Guide, A01, September 2021
- [6] HP Enterprise, HPE ProLiant DL160 Gen10 Server User Guide, 6, September 2020

Table of Contents

1. Preface	5
1.1. Conventions	5
1.1.1. Notes & Warnings	5
1.1.2. Typographic Conventions	5
1.1.3. Procedures	7
1.2. We Need Feedback	7
2. Introduction	8
2.1. Thank You	8
2.2. About This Guide	8
2.3. What is Infinity ES ^x ?	8
3. Start Here	10
3.1. Unpacking	10
3.2. Front & Back Panel – Dell PowerEdge R450	11
3.3. Front & Back Panel – HPE ProLiant DL160	12
3.4. Hardware Options	13
3.4.1. Solid State Disks (SSDs)	14
3.4.2. RAID-5 Disk Configuration	14
4. Installation	15
4.1. Safety Information	15
4.2. General	15
4.3. Location	15
4.4. AC Power	16
4.5. Local Area Network	16
4.6. Initial Run	17
5. Initial Configuration	19
5.1. Network Configuration	20
5.2. Recording	21
6. Basic Operation	22
6.1. Recording Repository Access	22
6.2. Live Monitoring	23
6.3. Automatic Archiving – Web Repository	25
6.4. Automatic Archiving – Network Repository	26
6.5. Automatic Archiving – USB Disk	26
7. Preventative Maintenance	28
7.1. Disks	28
7.2. Disk and Database Space	28
7.3. Orderly Shutdown	29

8. Troubleshooting 30

8.1. *Limited Product Warranty* 30

8.2. *Support Information*..... 30

1. Preface

1.1. Conventions

Our guides use several conventions to highlight certain words and phrases and draw attention to specific pieces of information.

1.1.1. Notes & Warnings

We use the following visual styles to draw attention to information that might otherwise be overlooked:



Notes are tips, shortcuts or alternative approaches to the task at hand. Ignoring a note should have no negative consequences, but you might miss out on information that makes your life easier.



Important boxes detail things that are easily missed. Ignoring the information will not cause data loss but may cause irritation and frustration.





Warnings should not be ignored. Ignoring warnings will most likely cause data loss or incorrect function.

1.1.2. Typographic Conventions

We use typographic conventions to call attention to specific words and phrases. These conventions and the circumstances they apply to are as follows.

<i>Example</i>	<i>Meaning</i>
Select <u>Guide</u> to display ...	Locate the link named "Guide" on the screen and then either: <ul style="list-style-type: none">• Position the cursor over the link and then depress the appropriate mouse button to follow the link; or

	<ul style="list-style-type: none"> • Tap on the link with a single finger to follow the link.
Select Add to ...	<p>Locate the button or menu item named "Add" on the screen and then either:</p> <ul style="list-style-type: none"> • Position the cursor over the button or menu item and then depress the appropriate mouse button to initiate an action; or • Press the button with a single finger to initiate the action.
Select  to ...	<p>Locate the button or menu item with the icon “” on the screen and then either:</p> <ul style="list-style-type: none"> • Position the cursor over the button or menu item and then depress the appropriate mouse button to initiate an action; or • Press the button with a single finger to initiate the action.
Enter <i>Commission</i> ... or Set <i>Commission</i> ...	<p>Locate the field named "Commission" on the screen and then either:</p> <ul style="list-style-type: none"> • Position the cursor over the field and then depress the appropriate mouse button to select the field. Once the cursor appears in the field, enter a value; or • Tap on the field with a single finger to select the field. Once the cursor appears in the field, enter a value.
Choose <i>Country</i> ...	<p>Locate the field named "Country" on the screen and then either:</p> <ul style="list-style-type: none"> • Position the cursor over the field and then depress the appropriate mouse button to display the available options. Then position the cursor over the desired option and depress the appropriate mouse button to select it; or • Press on the field with a single finger to display the available options. Then tap with a single finger on the desired option to select it.
Tick <i>Active User</i> ...	<p>Locate the check box named "Active User" on the screen and then either:</p> <ul style="list-style-type: none"> • Position the cursor over the check box and depress the appropriate mouse button to place a visual tick in the box; or • Tap on the check box with a single finger to place a visual tick in the box.

Un-tick <i>Active User</i> ...	Locate the check box named "Active User" on the screen and then either: <ul style="list-style-type: none">• Position the cursor over the check box and depress the appropriate mouse button to remove the visual tick in the box.• Tap on the check box with a single finger to remove the visual tick in the box.
Enter \$30.95 ...	Enter "\$30.95" using the keys on your physical or on-screen keyboard.

1.1.3. Procedures

We use a numbered sequence of steps to define procedures for performing specific tasks. For example:

Procedure Title

1. This is the first step of the procedure.
2. This is the second step of the procedure.
 - a. This is the first sub-step of step two.
 - b. This is the second sub-step of step two.
3. This is step three.

1.2. We Need Feedback

If you find a typographical error in this guide, or if you have thought of a way to make this guide better, then we would love to hear from you.

Please submit your feedback to <mailto:feedback@prolancer.com.au>.

If you have a suggestion for improving the guide, try to be as specific as possible when describing your suggestion. Otherwise, if you have found an error, please include the section number and some of the surrounding text to help us locate it.

2. Introduction

2.1. Thank You

Congratulations on purchasing the latest generation Total Recall VR Infinity professional audio logging and call recording appliance. Thank you.

Total Recall VR has more than 20 years of history of creating professional audio logging and call recording systems that are self-contained, fully featured and cost-effective. Enterprises and governments worldwide use Total Recall VR products to create electronic records of many forms of audio communication, including telephone, 2-way radio, broadcast radio, public address, intercoms, room microphones and much more.

2.2. About This Guide

This guide contains information intended to get you recording as quickly as possible with your new Total Recall VR appliance.

However, to enjoy the maximum benefit from your purchase, we recommend that you carefully read the following additional documents:

- Total Recall VR Cockpit User Guide [4].

2.3. What is Infinity ES^X?

Total Recall VR Infinity ES^X is an appliance based on commercial off-the-shelf enterprise-grade server hardware such as the Dell PowerEdge R450 and the HP Enterprise ProLiant DL160.

The appliance combines the latest generation Linux operating system and a suite of Total Recall VR Infinity recorder services engineered to run on commercial off-the-shelf enterprise-grade server hardware. Infinity ES^X appliances can be used as recording or archive appliances.

As a recording appliance, Infinity ES^X supports IP (VoIP, RoIP, AoIP, etc.) recording channels and is capable of recording:

- SIP sessions (calls) via UDP/TCP ports.
- SIPrec sessions via UDP/TCP ports.
- Cisco BiB sessions via UDP/TCP ports.
- Unicast and multicast RTP streams via SPAN ports.
- Unicast and multicast RTP streams via UDP ports.
- RTSP sessions via UDP/TCP ports.
- ATC recording via ED-137B/C Part 4.
- RoIP (analogue, MPT-IP and DMR networks) recording via Tait VRP.

- RoIP (DMR networks) recording via Hytera HDAP.
- RoIP (analogue, DMR, P25, NXDN ... networks) recording via Omnitronics RTP.
- RoIP (analogue, DMR, P25, NXDN ... networks) recording via Zetron SIP logging interface.

As an archive appliance, Infinity ES^X is a repository (archive) for recordings and associated metadata and a repository (archive) for audit events.

In all cases, users access Infinity ES^X appliances via instances of Total Recall VR Cockpit [4], the user interface for the latest generation Total Recall VR Infinity appliance and custom recorders.

3. Start Here



If a ruling is required on the legality of recording in your country, please seek legal advice from a legal professional.

THIS PRODUCT MUST NOT BE USED FOR ILLEGAL OR UNAUTHORISED RECORDING PURPOSES.

3.1. Unpacking

Please use care and assistance when unpacking, lifting and moving your Total Recall VR appliance.



DO NOT DROP your Total Recall VR appliance. It contains sensitive electronic components.

Check the box for damage. For example, a crushed box, holes, or water damage could indicate that the Total Recall VR appliance has been damaged. Open the box and inspect the Total Recall VR appliance and the associated accessories.



Contact your supplier or us immediately if your Total Recall VR appliance appears damaged. Save all packaging and, if possible, take photos showing the damage to all packaging and the Total Recall VR appliance.

Check that you have received the following in the box:

1. The Total Recall VR appliance and the associated accessories (power cables, mounting rails, face plate and keys for the face plate).
2. A USB thumb drive containing Total Recall VR manuals (including this one) and installation files for Total Recall VR PC applications.



If items are missing, immediately contact your supplier or us to arrange replacements.

3.2. Front & Back Panel – Dell PowerEdge R450



The definitive guide for the information in this section is the Dell EMC PowerEdge R450 Technical Manual [5].

Your Total Recall VR appliance's front panel features a security bezel that prevents unauthorised access to the system disks. The following screen capture shows the front panel with the security bezel removed.



<i>Item</i>	<i>Description</i>	<i>Note</i>
A	Easy swap disk caddies.	Two or four caddies will contain disks depending on the RAID configuration.
B	Power on/off button	
C	Console port	Connect a standard VGA monitor to this port if required.
D	USB port	Connect a USB keyboard to this port if required.

The back panel of your Total Recall VR appliance has a standard set of connectors.



Item	Description	Note
A	LAN port 1	Use this port to connect your appliance to your enterprise LAN.
B	LAN port 2	Use this port for recording IP traffic.
C	iDRAC management port	Use this port to access the iDRAC on your Dell server.
D	USB 3.0 ports	Connect a USB drive to use as a Total Recall VR archive. Support maximum output current of 0.9A.
E	Console port	Connect a standard VGA monitor to this port if required.
F	Power connector 1	
G	Power connector 2	

3.3. Front & Back Panel – HPE ProLiant DL160



The definitive guide for the information in this section is the HPE ProLiant DL160 Gen10 Server User Guide [6].

Your Total Recall VR appliance's front panel features a security bezel that prevents unauthorised access to the system disks. The following screen capture shows the front panel with the security bezel removed.



<i>Item</i>	<i>Description</i>	<i>Note</i>
A	Easy swap disk caddies.	Two or four caddies will contain disks depending on the RAID configuration.
B	Power on/off button	
C	USB port	Connect a USB keyboard to this port if required.

The back panel of your Total Recall VR appliance has a standard set of connectors.



<i>Item</i>	<i>Description</i>	<i>Note</i>
A	USB 3.0 ports	Connect a USB drive to use as a Total Recall VR archive. Support maximum output current of 0.9A.
B	iLO management port	Use this port to access the iLO on your HPE server.
C	Console port	Connect a standard VGA monitor to this port if required.
D	LAN port 1	Use this port to connect your appliance to your enterprise LAN.
E	LAN port 2	Use this port for recording IP traffic.
F	Power connector 1	
G	Power connector 2	

3.4. Hardware Options

Your Total Recall VR appliance may have been fitted with the following hardware options to customise it to fit your environment better.

3.4.1. Solid State Disks (SSDs)

This option replaces the standard 2.5" SAS hard disk with 2.5" SAS solid state disks (SSDs).

3.4.2. RAID-5 Disk Configuration

This option replaces the standard RAID-1 disk configuration with a RAID-5 disk configuration.

4. Installation

4.1. Safety Information

Always follow basic safety precautions when installing your Total Recall VR appliance to reduce the risk of injury from electrical shock and fire.



WARNING: Potential shock hazard. Total Recall VR appliances must be installed by qualified personnel.

Observe the following:

1. Read and understand all instructions in the Total Recall VR guides.
2. Follow warnings and instructions on labels on the product.
3. Use only grounded electrical outlets when connecting your Total Recall VR appliance to a power source. If unsure if an outlet is grounded, have a qualified electrician check it.
4. First, connect your Total Recall VR appliance to a grounded power outlet, and then connect the telephone lines.
5. Do not touch the contacts on the ends of any cables used with your Total Recall VR appliance. If any cable becomes damaged, then have it replaced immediately.
6. Shut down and unplug your Total Recall VR appliance from telephone jacks and power outlets before moving or cleaning.
7. Do not open your Total Recall VR appliance. There are no user-serviceable parts inside it. Refer all servicing to qualified personnel.

4.2. General

Your Total Recall VR appliance is computer equipment and generally has the same physical and electrical requirements as a computer server. Attention should be paid to the environment to ensure a long life and reliable operation.

4.3. Location

When choosing a location for your Total Recall VR appliance, consider the following:

- **Convenience.** Make the unit accessible to operators and service personnel who need to access it.

- **Security.** Users with access to the unit can remove power, disconnect cables and possibly compromise the recordings on your Total Recall VR appliance. User logins are no protection against determined attackers with physical access to the appliance.
- **Operating environment.** Your Total Recall VR appliance requires adequate cooling, a clean and always-on power source, a vibration and shock-free surface and protection from liquids.



DO NOT place your Total Recall VR appliance in enclosed cupboards, a damp or dusty room or a location with direct exposure to sunlight. Doing so will severely reduce the lifetime of your Total Recall VR appliance and void the warranty.

4.4. AC Power

Your Total Recall VR appliance uses a “universal” switching AC-to-DC power adapter. This means you can plug the power adapter into any line (mains) voltage from 100 Volts to 240 Volts AC nominal.



However, to prevent unplanned shutdowns caused by power glitches or interruptions, we strongly recommend using an Uninterruptible Power Supply (UPS).

Always use only grounded electrical outlets when connecting your Total Recall VR appliance to a power source. If unsure if an outlet is grounded, have a qualified electrician check it.

4.5. Local Area Network

Connect at least one network interface to a network that has DHCP enabled and provides network access from at least one device (PC) that will run an instance of Total Recall VR Cockpit.

To simplify the initial configuration process, we recommend connecting both network interfaces to a network, either the same or different networks.



Ideally, you will connect your Total Recall VR appliance to your enterprise network via the first LAN interface and your IP communication network via the second LAN interface.

4.6. Initial Run

You can power your Total Recall VR appliance once you have completed the physical installation of the appliance and connected the appliance to your network. However, we recommend that you delay that for a moment until you complete the following:

1. Install and activate an instance of Total Recall VR Cockpit on a device (usually a Windows-based PC) with network access to at least one of the networks to which your Total Recall VR appliance is connected.

See the Total Recall VR Cockpit User Guide [4] for information on installing and activating a Total Recall VR Cockpit instance.

2. Temporarily connect a standard VGA monitor to the console port of your Total Recall VR appliance.

Once the appliance is up and running, you can get the IP addresses assigned to its network interfaces by the DHCP servers from the console. For example:

```
Fedora 34 (Thirty Four)
Kernel 5.14.9-200.fc34.x86_64 on an x86_64 (tty1)
LAN1 IP: 192.168.130.153
LAN2 IP: 192.168.130.199
trvr-0x100-002 login: _
```

Now, configure an Appliance Recorder Node in the Manager view of the Total Recall VR Cockpit.



For information on configuring an Appliance Recorder Node using the Manager view, see the Total Recall VR Cockpit User Guide [4].

For example, to access the appliance that is shown on the previous screen capture via the interface with IP address 192.168.130.153:

Recorder Node

Appliance Recorder Node

Recorder: TRVR Appliance 130.153

System Service

Base URL: ssh://trvr@192.168.130.153:22

Refresh Done

Custom Recorder Node

You will gain management and monitoring access to the appliance once you create the node and are ready to proceed with the initial configuration.



To protect the integrity of the Total Recall VR appliance, we do not disclose the password to the root user or any other operating system user.

You must use the Total Recall VR Cockpit to manage and monitor the appliance.

5. Initial Configuration



The definitive guide for the information in this section is the Total Recall VR Cockpit User Guide [4].

This section contains information that will help you complete the initial basic configuration of your Total Recall VR appliance.

Before you proceed with the initial configuration of your Total Recall VR appliance, make sure that:

- The Total Recall VR appliance is up and running;
- You have a running instance of Total Recall VR Cockpit that can access the appliance over your network.
- You have created an Appliance Recorder Node in the Management view of Total Recall VR Cockpit to one of the network interfaces of the appliance – see section 4.6 Initial Run.

Continuing with the example from the previous sections, where we created an Appliance Recorder Node for the appliance with network interface with IP address 192.168.130.153, the following screen capture shows the Manager view of Total Recall VR Cockpit when it is ready to perform the initial configuration:

The screenshot displays the Total Recall VR Cockpit Manager interface. At the top, a status bar shows the date and time (17 Nov 2021 10:24:57) and the managed appliance (TRVR Appliance 130.153). The interface is organized into three main sections:

- Recorder Services:** A table listing various services and their status.

Type	Instance	Status
Audit Event REST Service	trvr.aers	Active
Audit Repository House Keeper	trvr.arhk	Active
Audit Repository IPC Connector	trvr.aric	Active
Database Service	trvr.db	Active
Media Repository Archive Connector	trvr.mrac	Active
Media Repository House Keeper	trvr.mrhk	Active
Media Repository IPC Connector	trvr.mric	Active
Meta Data REST Service	trvr.mdrs	Active
Monitoring Service	trvr.mms	Active
Profile REST Service	trvr.prrs	Active
Recording Service	trvr.mrs	Active
Recordings REST Service	trvr.cfrs	Active
RTP Media Server	trvr.rtpms	Active
RTSP Media Server	trvr.rtpms	Active
SIP Media Server	trvr.sipms	Active
Tail VRP Media Server	trvr.vrps	Active
- Service Manager:** A central panel for configuring services. It shows the 'Recording Service' configuration with fields for 'Source' (applianceRecorder), 'Rollover Timer' (00:00:00), and 'Quiet Timer' (00:00:00). It also includes checkboxes for 'Log Events' under 'Session Events', 'Resource Events', and 'Meta Data Events'.
- System Manager:** A panel on the right containing configuration, control, and tools sections. The 'Configuration' section includes buttons for 'Date & Time', 'Network', 'Network Storage', 'License', and 'Support'. The 'Control' section has a 'Shutdown' button. The 'Tools' section includes buttons for 'Detach USB', 'Manage Disks', 'Upgrade', 'Get Logs', 'Tail Logs', and 'Request License'.

5.1. Network Configuration

Your Total Recall VR appliance has two network interfaces. Use one (usually the first one) to connect the appliance to the enterprise network and the other (usually the second) for recording.

The image displays two side-by-side screenshots of the 'Network' configuration window. Both windows show the same hostname: 'trvr-vx100-002.tsn.prolancer.com.au'. The left window is for 'Interface 1 (LAN 1)' with network device 'ens192'. The right window is for 'Interface 2 (LAN 2)' with network device 'ens224'. In both, the 'Automatic' checkbox is checked, and the IP address is set to 192.168.130.x/24 (153 for LAN 1, 199 for LAN 2). The gateway is 192.168.130.1 and the name server is 192.168.20.200. At the bottom of each window, a status box indicates 'Fetching hostname. Fetching connection configuration for all network interfaces. Done.'

As you may already know, the default configuration of both interfaces is automatic (via DHCP).



We recommend a static configuration for both network interfaces.



Exercise extreme caution when changing the configuration of the network interfaces – you may lose connection to the appliance if you misconfigure the network interface used for the current connection to the appliance.

To use static configuration, untick **Automatic**, specify **IP Address** and **Gateway**, and optionally, **Name Server** and **VLAN ID**.

If you lose the connection to the appliance while configuring the network interfaces, remember that you can get the current IP addresses assigned to the appliance's interfaces from a console. Once you know the IP addresses, you can create a new or update an existing Appliance Recorder Node in the Manager view of Total Recall VR Cockpit to regain access to the appliance.

5.2. Recording

To start recording with your Total Recall VR appliance, you may have to change the configuration of some or all of the following Total Recall VR recording services:

- “RTP Media Server”
- “RTSP Media Server”
- “SIP Media Server”
- “Tait VP Media Server”

In addition, although less likely, you may have to change the “Recording Service” configuration.

Finally, you may need to define address transforms and recording policies via the “Profile REST Service”.

6. Basic Operation




The definitive guide for the information in this section is the Total Recall VR Cockpit User Guide [4].

6.1. Recording Repository Access

Your Total Recall VR appliance has a built-in recording repository to store the recordings it creates. This repository provides a REST interface via the “Meta Data REST Service” and the “Recordings REST Service”.

The Explorer view of Total Recall VR Cockpit has a built-in browser for recordings stored in repositories with different types of access. The browser has a suite of recording management and productivity tools that work on recording files and metadata.

In addition, the Explorer view of Total Recall VR Cockpit has a built-in event player capable of processing multiple recordings in the correct time order. Use the event player to reconstruct the timeline of events (incidents) and listen to the events as they happened in time.



You need to create a Media Repository record, particularly a Web (Media) Repository record, in the Explorer view to access the recordings in the recording repository of your Total Recall VR appliance. For example:


As you may have already noticed, to configure a Web (Media) Repository, you need the base REST URLs for both the “Meta Data REST Service” and the “Recordings REST Service”. You can get the base URLs from the service runtime status, for example:

6.2. Live Monitoring

Your Total Recall VR appliance has a built-in media and metadata streaming interface (media feed). This interface is provided by the “Monitoring Service”, which can stream both media and metadata of recordings as they are recorded in real time.

The Monitor view of Total Recall VR Cockpit can connect to such media feeds and show the metadata of recordings in progress, automatically construct a visual


representation of a running timeline of the recordings in progress and play the media being recorded for the recordings appearing on the timeline.



You need to create a Media Feed record in the Monitor view to access the media feed on the Total Recall VR appliance. For example:

The screenshot shows the 'Media Feed' configuration window. It has a title bar with a close button. The main area contains a 'Feed' dropdown menu set to 'TRVR Appliance 130.153'. Below this is a 'System Service' section with a 'Base URL' text field containing 'rtsp://192.168.130.153:1554/monitor'. To the right of the text fields are three icons: a plus sign, a document with a pencil, and a document. At the bottom are 'Refresh' and 'Done' buttons.

As you may have already noticed, to configure a Media Feed, you need the base RTSP URL of the feed. You can get the base URL from the runtime status of the “Monitoring Service”, for example:



Service Manager

Type:

Instance:

Configuration | **Control**

Service

Status:

Operations: ☐ Start ☐ Stop

Application

Status:

Version:


Base URL:

Operations: ☐ Start ☐ Shutdown ☐ Terminate

Sessions

Licensed:

In Progress:

 Refresh

6.3. Automatic Archiving – Web Repository

Ideally, you will configure your Total Recall VR appliance to archive recordings to a Total Recall VR archive appliance.



A working archiving strategy must be implemented to avoid losing recordings due to auto-cleaning. See section 7.2 Disk and Database Space.

However, to do so, you must first purchase a Total Recall VR Infinity archive appliance and then configure the “Media Repository Archiving Connector” service to use it.



For complete and detailed instructions on how to set up automatic archiving to a Web Repository, see the Total Recall VR Cockpit User Guide [4].

If you do not own a Total Recall VR Infinity archive appliance, your next best option is to archive to a Network Repository – see the following section.

6.4. Automatic Archiving – Network Repository

If you do not own a Total Recall VR Infinity archive appliance, we recommend configuring your Total Recall VR appliance to archive recordings to a Network Repository.



A working archiving strategy must be implemented to avoid losing recordings due to auto-cleaning. See section 7.2 Disk and Database Space.

However, to do so, you must first create a Network Repository and then configure the “Media Repository Archiving Connector” service to use it.



For complete and detailed instructions on how to set up automatic archiving to a Network Repository, see the Total Recall VR Cockpit User Guide [4].

6.5. Automatic Archiving – USB Disk

If you do not own a Total Recall VR Infinity archive appliance and cannot create a Network Repository (see previous two sections), you can archive to a USB disk attached to your Total Recall VR appliance.



A working archiving strategy must be implemented to avoid losing recordings due to auto-cleaning. See section 7.2 Disk and Database Space.

Generally, you can use any USB disk that you can attach to your Total Recall VR appliance recorder, however:

- Prefer brand new and unused disks.
- Prefer USB 3.1 or USB 3.0 disks. Avoid USB 2.0 disks at all costs.

- Disks with less than 128GiB capacity are unlikely to have enough capacity for a Portable Repository with the maximum allowed occupancy. At the same time, much space may be wasted on disks with more than 500GiB. This, of course, depends on the length of your recordings; shorter recordings have smaller file sizes, while longer ones have larger file sizes.

USB disks, in particular thumb drives, generally come preformatted with an NTFS file system, and as a result, they can be used straight out of the box. However, you can use unformatted disks and disks with a FAT32 and an exFAT file system.

Once you attach a USB disk to your Total Recall VR appliance, configure the “Media Repository Archiving Connector” service to use it as a Portable Repository.



For complete and detailed instructions on setting up automatic archiving to a Portable Repository, see the Total Recall VR Cockpit User Guide [4].

7. Preventative Maintenance

All Total Recall VR appliances require minimal preventive maintenance to ensure maximum performance.

7.1. Disks

The physical disks in all Total Recall VR appliances are the hardest working component. Information is constantly written to and read from the disks.

The average life expectancy of any type of disk is about four years. However, as with any electronic and mechanical technology, the disks in your recorder may last much longer or much shorter.

We recommend replacing the physical disks used by your Total Recall VR appliance every four years.



Your Total Recall VR appliance is fitted with a hardware RAID controller. Use the hardware manufacturer management tools to manage the system disks and the RAID.

Total Recall VR Cockpit cannot be used to manage the system disks and the RAID on your Total Recall VR appliance.

7.2. Disk and Database Space

All Total Recall VR appliances manage disk and database space automatically. An integrated auto-cleaning function ensures enough free disk and database space to record endlessly.



A working archiving strategy must be implemented to avoid losing recordings due to auto-cleaning.

The “Media Repository House Keeper” service performs the auto-cleaning function. By default, it automatically starts deleting recordings when the database occupancy reaches 100% or the disk occupancy reaches 95%, whichever occurs first. It removes the oldest first recordings until the database occupancy is at or below 85% and the disk occupancy is at or below 80%.

However, you may be using different limits on your appliance, so check the configuration of the “Media Repository House Keeper” service.


7.3. Orderly Shutdown

You must power down your Total Recall VR appliance in an orderly fashion to prevent damage to its electronic components, particularly its disks, and prevent partial or total information loss.



DO NOT remove power or turn off any Total Recall VR products while in use. This will result in disk damage and, most likely, partial or total information loss. In addition, it may cause damage to other electronic components. Finally, it will void the warranty.

To shut down or restart a Total Recall VR appliance in an orderly fashion, use the **Shutdown** control:



8. Troubleshooting

8.1. Limited Product Warranty

To view the full details of the limited product warranty for this Total Recall VR product, please visit our website: <http://www.totalrecallvr.com/warranty>.

8.2. Support Information

If, after using this manual and other related Total Recall VR manuals and in particular, the Total Recall VR Cockpit User Guide [4], you still have questions about the operation of your Total Recall VR products and applications or you are experiencing problems with your Total Recall VR products and applications, then:

1. Please visit the Total Recall VR online forums, <http://www.totalrecallvr.com/forum>, to find answers to common problems you may experience when installing and using Total Recall VR products.
2. Please browse the Total Recall VR online articles and tutorials, <http://www.totalrecallvr.com/articles-and-tutorials>, where you may find information on how to use Total Recall VR products combined with products from other manufacturers.




If you continue to experience problems, then in all cases, you should seek support from the point of purchase first.

If you need to contact us directly and require remote support, please write to itsupport@prolancer.com.au to book a remote support session.



You need to provide a valid and active support token when you seek support to receive support directly from us for your Total Recall VR product.

Use the Support tool to determine the status of your support token as shown on the following screen capture:



If the **Status** of the support token is not *Active* or it has expired, then you will need to renew the support token or purchase a new one before you can receive support from us.

Please note the following regarding the support token:-

- a. You do not need to purchase support tokens for any of your Total Recall VR products if you do not wish to receive support directly from us. Please discuss your support options with a representative from the point of purchase. They may and should offer support options that are likely to be tailored to your case compared to the remote support we provide as the manufacturer of the products.
- b. Support tokens are valid for one (1) year starting from the date that is exactly one (1) month after the date when the product that it relates to was shipped from our factory. Support for the first month after the shipment date is free and does not require a valid support token. So, during the first year, if you purchase a support token for a product at the same time when you purchase the product, then you will receive thirteen (13) months of support from the shipment date of the related product. You will receive twelve (12) months each subsequent year if you renew the support token.
- c. Each token relates to one instance of a Total Recall VR product and cannot be transferred to another instance of the same Total Recall VR product or used to get support for an instance of another Total Recall VR product.
- d. On expiry, support tokens can be renewed on a back-charging basis. You must pay for years missed and the current year when you renew an expired token. For example:

Suppose you purchased a support token when purchasing an instance of a Total Recall VR appliance. Further, let's take the fact that you did not renew the token or buy a new one after it expired at the end of the first year. If you request support in year 3 of ownership, you must pay for two years of support (to cover support for years 2 and 3) to renew your existing token or purchase a new one. The purchase will give you a token expiring at the end of year 3.
- e. You can purchase a support token anytime on a back-charging basis for any Total Recall VR product instance. For example:

Let's assume you did NOT purchase a support token when you purchased an instance of a Total Recall VR appliance. If you request support in year 3 of ownership, you must pay for three years of support (to cover support for years 1, 2 and 3) to purchase a new support token. The purchase will give you a token expiring at the end of year 3.



In summary, if you wish to receive support directly from us for an instance of a Total Recall VR product, then you need a valid and active support token for the instance of the Total Recall VR product.

However, you do not need to purchase support from us. Instead, please discuss your support options with a representative from the point of purchase. They may and should offer support options that will likely be tailored to your case compared to the remote support we provide as the manufacturer of Total Recall VR products.

[End of Document]